



# LS302 Installation Instructions

**Larsen & Shaw Limited**

www.larsenhinge.com

575 Durham Street, Walkerton, ON N0G 2V0

Ph: 800-265-3078 • Fax 519-881-3575

All holes in the hinge must be drilled correctly and fasteners properly installed. Failure to use the fasteners supplied by Select Products Limited will void the UL fire rated listing.

Do not install Snap-On cover until installation is 100% complete, and all aspects of the assembly are correctly fastened and properly fitted.

The Screw Pack contains self-drilling machine screws. These self-drilling Tek screws are also recommended for grout-filled frames.

- Perform each step of these instructions.

- (1) Place hinge on frame as shown in Figure 1 on the other side of these instructions.
- Allow 1/8" between top of hinge and underside of header.

Note that at least 1 5/8" of frame face is required for mounting this hinge.

- (2) Mark the position of the top and bottom holes with a center punch, then drill and fasten. The use of the center punch can help center the hole so that the fasteners will enter straight.

- (3) After the top and bottom screws are installed, drill and fasten the balance of the holes. Install at least five cover clips by passing a screw through the clip, hinge leaf and frame. (See Figure 2)

- Select recommends that clips be positioned in the top, center and bottom holes, with the remaining clips spaced equally along the length of the hinge.

- (4) Fold the door leaf back over the frame leaf and place the door in the door frame.
- Place shims under the door to provide 1/8" clearance between the header and the top of the door.
  - Add shims at both the hinge and latch side of the door so that 1/8" clearance will be maintained equally on the lock side of the door.
- (5) With the door held firmly in place, return the door leaf to the face of the door and repeat the drilling procedure described in steps (2) and (3).
- Molly Jacknuts and aluminum sleeve bolts (Select part numbers MP-20 and MP-22) are available from your hardware supplier as an optional means of attaching the door.
  - **Steel sleeve bolts (part # MP-23) must be used on mineral core wood fire doors.**
- (6) Install the Snap-On covers by engaging the side of the cover next to the hinge pin first.
- (7) Insert a large screwdriver between the hinge knuckle and the cover. Using the screwdriver as a lever, twist it and snap the opposite side of the cover onto the clip.
- (8) Start at the top and work downward until the entire length of each cover is firmly engaged.
- (9) With the covers firmly in place, secure them at both ends through the hinge and into the door and frame with #8 x 3/4" self-drilling flat head Tek screws.